



Push-to-talk

Push-to-talk allows you to call the FM device and talk to the driver directly. No specific installation is needed – plug the 3.5 mm connector into the audio jack and you are good to go. Communication is half duplex (one way). When the button is released, the driver can hear the caller, when the button is pressed, the driver can talk.

- Communication with driver
- Plug and play, no installation needed
- Half duplex channel

Electrical specifications	
Impedance	8 Ω
Physical properties	
Dimensions	75 x 45 x 20 mm (30 mm with grip)
Cable length	55 cm (2 m with extension)
Connector	3.5 mm TRRS connector
Pinout	
<p>The diagram shows a TRRS male connector with four pins. Pin 1 is labeled 'WHITE Dynamic-', pin 2 is 'GREEN Dynamic+', pin 3 is 'BLACK MIC-', and pin 4 is 'RED MIC+'. The connector is labeled 'TRRS male pinout'.</p>	
<p>Note: make sure that the Enable list for voice calls checkbox is ticked in the configurator (Authorized numbers settings)</p>	
Compatibility	
FM-Tco4 HCV FM-Tco4 LCV FM-Pro4	Yes
FM-Eco4 FM-Eco4 S	No
FM-Eco4 light FM-Eco4 light S	No
FM-Plug4	No

Ordering information

Push-to-talk

Push-to-talk voice transceiver

Warnings



Waste equipment should not be disposed of with your other household waste. The product must be taken to separate collection points at the product's end-of life.

Document application

Given parameter values and various characteristics within this document apply only to the most recent product hardware version.

Legal information

All rights reserved. Reproduction, transfer, distribution or storage of parts or all of the contents in this document in any form without the prior written permission of Ruptela is prohibited. Other products and company names mentioned in this document are trademarks or trade names of their respective owners.

Contact information:

Ruptela
Perkunkiemio g. 6
LT-12130 Vilnius, Lithuania
Phone: +37052045188
Web: www.ruptela.com

Datasheet v1.5
2019-01-16
Copyright © 2019 Ruptela